



INSTALLATION CIRCUIT



FILLING THE LIQUID MEDIUM



MORE INFO & HELP

Email ENERA: info@enera-solar.com

Call ENERA: +34 634 799 310

F.A.Q: www.enera-solar.com/faq/

Manuals: www.enera-solar.com/download/

Warranty: www.enera-solar.com/warranty-terms/

WARRANTY

- The warranty of all installed equipment is 2 years
- This period is valid if the magnesium corrosion anode is replaced every 12 month
- In the long-term non-use of the solar heater, it is recommended to close the cold water supply to the system for more than 72 hours
- The system must only be started when there is no sun
- That is, during the morning or the night
- Filling the tank during the day leads to its failure, the guarantee would NOT be valid


WARRANTY CARD

System:

Installation Date:

INSTALLATION MANUAL

www.enera-solar.com



ENERA-X


Forced Circulation Solar Water Heating Split System

INTRODUCTION

Please read all Installation instructions carefully before beginning system design or installation. The configuration to the system may have to be customized to suit requirements specific to the installation. Please guarantee that any design system fits the construction of local, and water quality standards.

Installation must be completed in accordance with the local rules and regulations.

Installation must be completed by professionals qualified plumbing.



PRESSURE AND TEMPERATURE CONTROL WATER QUALITY

The Solar circuit must be designed for operation normal at <500 Kpa (5 bar - 72.5 lbs / in.B) through use of a pressure limiting valve (pressure reducing) in the supply line of the cold water supply. The system design should provide a valve for the pressure that allows release in no more than 800 Kpa (8 bar - 116 lbs / in.B) and a buffer tank (expansion) for hot water from the heating circuit solar energy or storage tank once the temperature reaches 99°C. (210°F.) If the system stalls, I know recommends that the pressure valve lever and the temperature (PTRV) are operated once every 6 months to ensure reliable operation. It is important to raise and lower the lever gently.

The water in direct flow through the distributor head (manifold) must first meet the water requirements drinkable and also in the following text: Total Solids Dissolved <600mg / liter or ppm Total hardness <200mg / liter or ppm Chloride <250mg / liter or ppm Magnesium <10mg / liter or ppm In "hard water" areas of the scale (> 200ppm), in the distributor line inside the pipe. In those field regions, a water softening device to ensure long-term effective collector operation, or use a closed circuit for solar circulation. If glycol / water solution shall meet the requirements above, and the glycol should be changed periodically to prevent glycol from becoming acid.

METALLIC CORROSION

Both copper and stainless steel are susceptible to corrosion when high chloride concentrations are present. The solar collector can be used for temperature of the spa or pool water, but free chlorine levels should not exceed 2 ppm, in addition to the warranty provided by the dealer when used for tempering of the pool or spa is 3 years, which is the standard for spa and heated pools.

PROTECTION AGAINST FREEZING

The freeze protection of the system must incorporate an electronic controller of the solar energy, by using the "low temperature collector" configuration, which turns the pump on if the manifold drops below a preset level (Ex. 5 ° C / 41 ° F.). Alternatively a closed circuit filled with a water-glycol mixture can be used to provide freeze protection. Vacuum tubes are not sensitive to cold damage, the water inside the heat pipes are protected against damage caused by freezing.

HAIL RESISTANCE

Glass vacuum tubes are surprisingly strong and capable of handling a significant impact once installed. Stress and impact test on a model demonstrates that the tubes are capable of withstanding hail impact of up to 25mm / 1 "in diameter when installed at an angle of 40 ° or more. Vacuum tubes capacity to withstand the impact of hail is more influenced by the angle of impact and in order to installing the collectors at low angles does not reduce their impact resistance. However, even though as indicated, the impact by hail up to 20mm / 3/4 "in size does not cause breakage. It is recommended that in areas prone to large hail (> 20mm./3/4 ") the solar collector should be installed at an angle of 40 ° or more to provide a optimal protection. As many in populated areas of the world fall within the margin 30-70 ° ± in general from this point of view, it is a common installation of all modes. If in the unlikely circumstance a tube is broken, it can be replaced easily in minutes. The solar collector can still work properly with one or more broken tubes, however it will result in a reduction in heat production (depending on how many tubes are broken).


TUBE INSPECTION

Open the tube box (s), containing both vacuum tubes and heat pipes (Heat Pipe). Make sure all vacuum tubes are intact and the bottom of each tube is still silver in color. While if you have a tube with a light bottom, it is damaged and should be replaced. Each vacuum tube contains a pair of metal fins for transfer of heat. As soon as the vacuum tubes are removed from the box, please put on the tube the rubber caps, which are in the collector box. This will protect the tip glass at the bottom of the tube, which breaks if struck. Do not remove protection and / or expose the tubes to sunlight until they are installed, otherwise the transfer of heat from the inner tube will become very hot. The outer glass surface is not heated up.

HEAT PIPES (HEAT PIPE)


If the (copper) heat pipes are bent during delivery, don't worry as there is no they are easily damaged. Just make sure they are relatively straight before insert into the vacuum tube.

ELECTRICAL INSTALLATION



H1 — resistencia termoelectrica
P1 — la bomba de circulación (captador- serpentín en acumulador)
T1 — termosensor T1
T2 — termosensor T2
T3 — termosensor T3

DIAGRAMA DE INSTALACION ESTANQUE ACS+CALEFACCION




BLEEDING THE AIR

Step 1: Open the valve V1, V3 and V4, close the V2, the filling pump connects at the point 1 where the antifreeze liquid is introduced, until the flow of liquid returns through point 2. Let the pump circulate for approx. 2 (up to 5) minutes. until everything is exhausted the air in the pipe.

Step 2: Close valve V3, then close V1 and turn off the pump.

Step 3: Connect the expansion vessel to valve V3 and open the valve, then open valve V2, which should be open forever. Commissioning of the station work, observing the balance between the valve (V5) to see if there is any air in the inside the pipe. If there is air inside the pipe, fill with the liquid antifreeze the system, again following the steps given above until the exhaust all air from the system.



ISOLATION

The plumbing and manifold pipes must be insulated. The foam of the insulation should be checked annually for damages. To protect the stabilized pipe insulation foam that is exposed to sunlight (UV rays), a metal sheath must be installed, otherwise rapid deterioration it can happen.